

Crimp Fittings

In case of press-type mechanical fittings, after cutting (it is always recommended to cut in orthogonal direction to the axis of the pipe), gauging and trimming, the pipe is put inside the fitting until the pipe that can be viewed through the suitable slots.

The stainless steel bush is pressed with the suitable tool, as shown below.

ATTENTION: every fitting size requires the use of the corresponding pressing tong.
It is recommended to check the compliance of these measures at every application.

Tool Preparation:

- 1. remove the safety pin;*
- 2. insert the pressing tong;*
- 3. insert the safety pin up to stop.*

